INSTRUCTION


-SWF-QP FLOOD LIGHT

- Read through this manual before installation.
- The product must be grounded.
- this product must be installed and maintained by certified electrician.
- Consult with the manufacturer before maintenance.
- Turn OFF the power before installation and maintenance.
- Make sure the products are securely installed.
- The housing might become hot after operation.
- Make sure the construction is strong enough to support the products.
- If the temperature is too high, the output power will be reduce until the temperature to normal.
- The external flexible cable or cord of this luminaire cannot be replaced; if the cord is damaged, the luminaire shall be destroyed.
- For all of the above installation, it is recommended that all models with safety rope.

Installation Instructions

The lamp is connected to the external high voltage schematic diagram:
Turn off the main power switch before connecting the lamp.
Connect the power line as shown in the figure below.







Turn off the Power switch


IP65 waterproof junction box
(Not equipped with lights)

Fixture input wire




Specification :





Installation :



	"A"	"B"	"C"	"D"
50W 70W	120mm [4.72"]	30.5mm [1.2"]	Ø13mm [Ø0.51"]	10.5mm [0.41"]
100W 150W 200W	150mm [5.91"]	60mm [2.36"]	Ø13mm [Ø0.51"]	11mm [0.43"]

Drilling hole specifications

